

# MC50


Mobile Computer

## Accessories Guide




### Standard


#### Adapters




PWR-18W-CN



PWR-18W-EU



PWR-18W-UK



PWR-18W-US

Adapter (CN/EU/UK/US), I/P: 100-240V, O/P: 5V3A/12V1.5A/9V2A, use with DC-BK-TypeC cable.

#### USB Cable



**DC-BK-TypeC**  
1.0 meter Type-C cable.

#### Battery



**BTRY-C50-50MA**  
Main battery, 5000mAh Li-on battery, Rated Voltage: 3.85V.

### Optional


#### Charging Cradles



**CRD-C50-RBC**  
Single Charging Cradle, DC port, charge device only, use with DCPWR-12V2A-XX adapter.



**CRD-C50-SCC**  
Single Charging Cradle, Type-C port, charge device only, use with 10W/18W adapter.



**CRD-C50-DBC**  
Single Charging Cradle, Type-C port, charge MC50 device with spare battery, use with PWR-18W-XX adapter.

#### Pistol Grip



**RB-C50-PS**  
Snap-On Trigger Handle and Rugged Boot Kit without battery.

#### Hand Strap



**RB-C50-HS**  
Hand Strap with buckle  
This include 2 pcs screws, 1 pcs wrist strap Buckle and 1 pcs hand strap.

#### Rugged Rubber Boot



**RB-C50-RR**  
RB-C50-RR does not support charging cradle.

#### Screen Protector



**SP-C50**  
Tempered glass screen protector.

#### Adapters



CN UK EU US

**DCPWR-12V2A-CN/UK/EU/US**  
Adapter (CN/EU/UK/US), I/P:100-240V, Pistol O/P:12V2A, DC